

**E400 Economy Window or Door Canopy
E450 Economy Door Canopy, E450 Economy Window Awning
Assembly and Installation Instructions**

Unpack and review parts.



Interlock all 4 panels together. The panel with the drilled holes is the back panel that will be attached to the house.



Use a self-tapping screw to connect the panels to each other where the panels overlap.



Slide assembled panels into the side rails and front rail.

The leg of the front rail should overlap the top legs of the side rails.

Use 8 self-tapping screws along each side rail, in the pre-drilled holes, to fasten rails to panels.

(An E400 Economy Door Canopy shown. On E450 Economy Canopies and Awnings, side rails are pre-assembled with the scroll sides.)



Attach the back panel of the awning to the house using the 1-1/2" hex head screws. If attaching to brick, block or concrete, you will need to use appropriate anchors (not included) available at hardware stores.

A bead of caulk is recommended between the back panel and the wall.



Attach the front of support arm with a self-tapping screw through the pre-drilled hole to the underside of side rail on each side.



Attach the back side of each support arm to the house with a 1-1/2" hex head screw.

The awning slope may be adjusted by positioning the back side of support arms higher or lower.



Installed awning.

